

# Link

with Universal Puck

## Getting Started Guide

Follow this guide to set up your Link with Universal Puck.

Locate the below items and continue to Step 1. Screws and Allen key are under the perforated tab in the packaging.



Link Stand



Universal  
Puck



Magnet Key




Allen Key




x2 Wood  
Screws

# Universal Puck



**Step 1** Measure your tablet's width and guide the cable through the corresponding adjustable path.



**Step 2** Plug Puck USB-C Cable into tablet and ensure Puck aligns to the center of tablet. If needed, re-adjust cable path to ensure cable has no slack.




**Step 3** Wipe down your tablet to be free from dirt and dust. Peel off the plastic from Puck adhesive.




**Step 4** With Puck USB-C Cable plugged in, align Puck to center of tablet, press down, and hold for 20 seconds.

# Freestanding


Follow the next 5 steps to change the base cable feed direction. If you don't need to change it, skip to **Step 6**.




**Step 1** Unscrew Backplate with Allen Key.




**Step 2** Unscrew inner screws using same Allen Key to release Baseplate.




**Step 3** Rotate USB-C Charging Port to preferred direction.




**Step 4** Place the Baseplate back on in your chosen cable feed direction. Slide to lock in place, then re-insert and tighten the two screws with the Allen key.



**Step 5** Reattach Backplate and screw in two screws using Allen Key.




**Step 6** Plug your charging cable into the USB-C Charging Port.




**Step 7** Place Puck onto Link Stand and adjust lock to preferred position with Magnet Key.


# Adhesive Mount




**Step 1** Unscrew Backplate with Allen Key.




**Step 2** Unscrew inner screws using same Allen Key to release Baseplate.




**Step 3** Rotate USB-C Charging Port to preferred direction.




**Step 4** Place the Baseplate back on in your chosen cable feed direction, with adhesive facing outward. Slide to lock in place, then re-insert and tighten the two screws with the Allen key.




**Step 5** Reattach Backplate and screw in two screws using Allen Key.



**Step 6** Plug your charging cable into the USB-C Charging Port.




**Step 7** Wipe down the surface to remove any dirt or dust, then peel off the plastic from adhesive. Press it onto the surface, and hold firmly for 20 seconds.




**Step 8** Place Puck onto Link Stand and adjust lock to preferred position with Magnet Key.


# Screw Mount




**Step 1** Unscrew Backplate with Allen Key.



**Step 2** Unscrew inner screws using Allen Key to release Baseplate.




**Step 3** Rotate USB-C Charging Port to preferred direction.




**Step 4** Use the Baseplate to mark pilot holes and screw down Baseplate to surface.




**Step 5** Plug your charging cable into the USB-C Charging Port.



**Step 6** Attach Link Stand onto Baseplate and slide to lock in place. Screw back in the two inner screws using Allen Key.



**Step 7** Reattach Backplate and screw in two screws using Allen Key.



**Step 8** Place Puck onto Link Stand and adjust lock to preferred position with Magnet Key.



US Customer Support

**1800 293 9703**

sales@bosstab.com

Australia Customer Support

**1800 870 132**

sales@bosstab.com.au

### **Warranty & Returns**

If you receive an item that is faulty or damaged then you can send it back for a refund, replacement or store credit & we'll pay for the return postage costs.

We offer a 12 month warranty on items that are deemed defective by the manufacturer. If you have a defective product covered by this warranty, we will either repair using new or refurbished parts, or if repair is not possible, replace the item. The warranty will not cover loss or theft, nor damage deemed to be caused by misuse or unauthorized modification. To view our full returns policy & initiate a return please visit [www.bosstab.com](http://www.bosstab.com)