BALANCE keyboard



The perfect partner. The perfect fit.

Balance Keyboard was made for you and the way you work. Specifically designed to fit RollerMouse Red, Red plus, and Free2, the Balance Keyboard puts your hands in the perfect typing and mousing position.

Comfort is key. Designed specifically for use with our award winning RollerMouse family, you'll be in an improved, stress-free position while getting the most out of your keyboard and mouse. Your hands stay closer to the action and within reach of both the rollerbar and keyboard keys.

Increased functionality at hand. The Balance Keyboard's media keys perform useful everyday tasks and can be programmed to suit your specific needs (Mac only). Traditional function keys (F1-F12) are also available, and the Fn lock feature makes them readily available when needed.

Power and freedom. It's time to cut the cord. The Balance Keyboard is wireless and runs on 2 AAA batteries. It connects to your PC or Mac by using its own USB wireless receiver.



The Balance Keyboard's adjustable legs and tilt options allow for negative, neutral, and positive typing angles.



This small, wireless receiver can be securely stored in the magnetized battery housing when not in use.



The low profile keys are offered in two layouts, Pan-Nordic and English. Scissor switch mechanisms provide a nice tactile feeling when typing.



BALANCE keyboard



Key Features

- A. Indicator lights for battery level, caps lock, and function lock.
- B. A slightly larger "A" key, to prevent accidental caps lock selection.
- C. Fn lock allows for immediate use of all programmed functions keys.
- D. Aligns perfectly with RollerMouse Red and includes a full number pad.
- E. Reduced bottom edge to minimize reach from rollerbar to keyboard.

Width	15.4in
Depth	4.7in
Height	0.8in
Key layouts available	Pan-Nordic, English
Connection	Wireless
Power source	2 AAA batteries
Driver needed	No
Customizable Media Keys	Yes (TBA)
Warranty	2 years from date of purchase
Compatibility	Mac and PC



Stay connected.

Use the Reset button to easily refresh the Keybord's settings once a driver has been installed, or if there is an issue with the wireless connection.

