

Element Hardware Cleaning Instructions

Important precautions before cleaning your Element product

- Turn off the power to the system and disconnect the power cable.
- Use a microfiber cloth.
- Never spray or pour the disinfecting liquid directly onto the product. Always spray it into the cloth, and make sure no liquid is dripping from the cloth.

Cleaning/disinfecting procedure for PCAP touchscreens

1. Turn off the power and disconnect the power cord.
2. Dampen a clean microfibre cloth with your Isopropyl alcohol 70%-75%*. **Ensure there is no fire or heat in the vicinity as alcohol is flammable.**
3. **Do NOT spray the disinfectant directly onto the system. Ensure there is no liquid dripping from the cloth.**
4. Disinfect the surfaces of the product starting with the touch screen, as it is the area that is touched the most.
5. Let the system dry before reconnecting power.

Do NOT use any other products to clean the system.

** Isopropyl alcohol 70%-75% is a recommended disinfection product by WHO and tested by Element. It is suitable for PCAP touch screens.*

Cleaning procedure for resistive touch screens

1. Use a soft lint-free cloth.
2. The cloth may be used dry, or lightly dampened with a mild cleaner or Ethanol.
3. Suitable cleaning products are commercially available pre-packaged for use; one example of such a product is [Klear Screen™](#), or commercially available off-the-shelf retail brands such as Glass Plus® Glass and Surface Cleaner made by [Reckitt-Benckiser](#). Cleaner must be neither acid nor alkali (neutral pH).
4. Be sure the cloth is only lightly dampened, not wet. Never apply cleaner directly to touch panel surface; if cleaner is spilled onto touch panel, soak it up immediately with absorbent cloth.
5. **When using cleaner, avoid contact with the edges of the film or glass, and with the flex tail.**
6. Wipe the surface gently; if there is a directional surface texture, wipe in the same direction as the texture.
7. **Never use acidic or alkaline cleaners, or organic chemicals such as: paint thinner, acetone, toluene, xylene, propyl or isopropyl alcohol, or kerosene.**
8. **Use of incorrect cleaners can result in optical impairment of touch panel and/or damage to functionality.**