


KIOSK01 (gen 2)

PROPER


Wall Mount

User Guide



What is Included


1x Wall Mount



Basic Dimensions

For an accurate hole pattern for the Wall Mount, refer to the drawings below.


Units: mm



Mounted Dimensions

For dimensions of the Wall Mount in relation to the KIOSK01 when mounted, refer to the drawings below.


Units: mm



IO Dimensions

For dimensions on the KIOSK01 rear IO when mounted, refer to the drawing below.


Units: mm



Clearance Zone


To avoid obstructing the KIOSK01 when mounted, refer to the drawings below.

Units: mm



Clearance Zone with Accessories

Units: mm




Instructions

Step 1:

Use the previous drawings to accurately mount the Wall Mount to your chosen surface. Make sure the orientation of the Wall Mount is as shown in the previous drawings with the narrow end of the mount protrusion towards the top.


Step 2:

To mount the KIOSK01 to the Wall Mount, remove the two fasteners and latch cover located on the side of the KIOSK01 exposing the latch button.



Step 3:

Begin by carefully aligning the KIOSK01 rear mount opening to the protrusion on the Wall Mount as shown below.





Step 4:

While pressing the side latch button, push the KIOSK01 toward the Wall Mount until the protrusion seats securely in the mount opening.

Keeping the KIOSK01 flush against the mount (1), carefully slide it downward until it no longer moves (2). Release the latch button to lock it in place.

Before letting go of the KIOSK01, gently wiggle it to confirm that it is securely mounted.



Step 5:

Finally, re-fasten the latch cover on the KIOSK01. Use the cavity marked below to neatly route cables into the chosen surface.

