


Universal Mount Disk Pro


PROPER

User Guide




What is Included

1x Mount Disk Pro




1x Connect Adapter



Base Dimensions

Use the drawings below with your selected tablet dimensions to confirm adequate wall clearance.


Units: mm



Mounting Dimensions

For an accurate mounting hole pattern and installations requiring a wall pass through hole for concealed in wall cable routing, please refer to the drawing below.

Units: mm



Instructions


Step 1:

Prepare the wall for installation. If you plan to conceal the cable, drill the hole and route the cable through it before continuing.

Step 2:


Use the Mounting Dimensions drawings (page 4) as a guide to select the appropriate hardware and accurately secure the Mount Disk Pro to the wall using screws. Refer to this drawing together with the following page to determine the correct location for drilling a cable pass through hole for a clean installation.

Use the drawing on the following page as a guide for routing the tablet charging cable through the pass through hole.




Step 3:

To mount your Connect Adapter to your chosen tablet begin by gently removing the 4 adhesive films using the pull tabs as shown below




Step 5:

Carefully align and place the Connect Adapter on to the chosen tablet. Apply steady pressure for 20-30 seconds to ensure a strong bond.



Step 6:

Position the tablet onto the mount surface of the Mount Disk Pro at a 45° angle, ensuring the X-shaped cavity on the Connect Adapter aligns and seats correctly with the corresponding X-shaped detail on the mount.



Step 7:

Once seated, rotate the tablet 45° until a click is heard.

